

DOWNLOADING PROCEDURES USING THE RDC-2 WITH A PC

SERIAL CABLE TRANSFER PC

- Ensure that you are in the **Ricoh PhotoStudio 2.0 Software**.
- Go to *File, Download Ricoh Files*.
- Select **RDC-2** as the *Source*, and either *Open to Album*, or *Open to Desktop*. The file type should be **Ricoh DSC J6I** format, however it can be changed to a file type of your choice.
- At this time, make sure that the camera is connected to the computer via the **RS232C serial cable** and inserted into the available com port. The camera should be in **Play (PC)** mode and the batteries fully charged or hooked to the **AC-2 A/C Adapter**.
- Once everything has been selected, click **OK**. The computer should time out for a few seconds.
- After the computer has seen a connection with the camera, you will see the *Camera Tool Selection*. This will enable you to select images from your camera. To select the current image in your **DM-2 NTSC LCD Color Monitor**, click on the selection box. To select a different image, click in the selection arrows, and once you have located the desired image, click the selection box. If you wish to change the selections that you have made, click on the *Reset* box. This will take you back to previous selection. To select all of the images, click on the *Select All* box. To select none of the images, click on the *Select None* box.
- After making your selections, click **OK**. This will open the connection and transfer the data from the camera to the computer. At this point, you should see the images either appear on the album, or in your desktop.
- If you are having problems downloading, try leaving your camera in the **Off** position until you have clicked **OK** on your computer. Wait 1 or 2 seconds, and turn the camera to **Play (PC)** position. If you have any further questions, please contact our Digital Technical Support Department.

PC CARD TRANSFERS

- Insert your **ATA Flash card** directly into your **PC card reader**.
- Open your **Ricoh PhotoStudio 2.0** software.
- The downloading procedures can be completed 2 (two) different ways. First, go into *File*, and select either *Download Ricoh Files*, or *Open Album*. If you are going through *Download Ricoh Files*, select the *Disk Drive* as the *Source*. Either *Open to Album*, or onto *Desktop*. Once you have selected your preferences, click **OK**. *Note: The images will be in a named format i.e.. 0R00006.j6i.
- If you are selecting *Open Album*, go to *Add*, and look in the Removable Disk drive. Once that has been opened, you can select which images you wish to add to the album. *Note: The images will be in a named format i.e.. 0R00006.j6i.