

Ricoh RDC-2 Digital Camera - Win 3.1 Technical Issues

Some technical problems related to PhotoStudio 2.0 and Ricoh RDC-2 Digital Cameras operating under Windows 3.1 are caused by the WIN 32S Library.

The following is the step by step procedure to make sure that you have correctly and completely installed the WIN32S library.

1. Launch Windows 3.1
2. Launch File Manager and go to C:\WINDOWS\SYSTEM directory
3. Double click on SYSTEM directory in the left hand side listing
4. Select the WIN32S directory
5. Press DELETE key and confirm it to delete the whole directory
6. Exit Windows 3.1
7. Launch the Windows 3.1 again (NOTE: it may have some messages about missing WIN32S files. Go ahead and press ENTER key)
8. Now it is ready to install WIN32S library shipped with the PhotoStudio 2.0. Go to File menu and Run sub-menu and type A:\SETUP.EXE
9. Following the installation of WIN32S Library, you may now install PhotoStudio 2.0

If you are experiencing odd problems using PhotoStudio under Windows 3.1 or if the program was functioning at an earlier date, but is now having difficulties - please follow those procedures listed above after uninstalling any current PhotoStudio 2.0 on your system.