

# RDC-7 Software




## Software CD Contents and Installation for Windows

The software contained on your CD is specially designed to operate with your RDC-7 digital camera. Please read the following information prior to installing you software to familiarize yourself with the contents of the CD.

### Software CD

ArcSoft



This folder group contains:

The ArcSoft setup folder for installing the ArcSoft Software Suite

A document folder that contains the software help files in PDF format and a PDF reader

A Phtoland folder that contains utilities to make using Phtoland easier.

To install the ArcSoft Software Suite, open the Arcsoft folder and double-click on the Setup.exe icon.



PhotoBase, an easy-to-use program that organizes albums of multimedia files  
PhotoStudio, a full-featured, easy to use image editor.

PhotoMontage lets you create a "mosaic" of a single image from a library of images.

PhotoPrinter allows you to print multiple images on a single sheet.

PhotoFantasy allows you to place personal images into background templates.

Phtoland software lets you make free personal photo albums on the Web.

VideoImpressions is an easy to use video editor.

PanoramaMaker lets you make 360 degree panoramics from your images.

Camera Utility



This folder contains Ricoh Camera Utility, a simple serial file transfer utility for your RDC-5300. Double-click on the Setup.exe icon to install. This program is not required to transfer files if you have installed PhotoBase.

CD Manual

The PDF version of this manual.

Explorer Plug-in

Installing this program will allow the RDC-7 to emulate as a disk drive for easy file transfer using Microsoft Explorer.

TWAIN Drivers



This folder contains the TWAIN drivers required to use the camera as a TWAIN device.



Double-click on the Setup.exe icon on disk one. A Set-up wizard will guide you through the installation.



To use the RDC-7 as a TWAIN device. You must use software that supports TWAIN.

When the camera is properly connected via a Serial connection, you may access the camera using the "Acquire" command from your software.

USB Drivers


This folder contains the drivers required to connect the camera to a USB port. When the camera is connected to a USB port for the first time, point the Hardware Wizard to read from this folder to install the drivers.

### Software Licensing Agreement

The following is a legal software license agreement between you, the software end user, and the companies of Ricoh corp. and ArcSoft, Inc. Carefully read this license agreement before using the product. Using the product indicates that you have read this license agreement and agree to its terms. If you do not agree to the terms, promptly return the package to the place where you purchased it within 10 days of the date you acquired it for a full refund. Grant of License. This license permits you to use one copy of the software included in this package on any single computer. For each software licensee, the program can be in use on only one computer at any given time. The software is in use when it is either loaded into RAM or installed into the hard disk or other permanent memory. A multi-seat license permit from ArcSoft and Ricoh is required if the program is going to be installed on a network server for the sole purpose of distribution by other computers, or if the program is going to be installed on and used by more than one computer. Copyright. The software contained in this package is owned by ArcSoft and Ricoh and is protected by United States copyright laws, international treaty provisions, and all other applicable national laws. The software must be treated like all other copyrighted materials (e.g. Books and musical recordings). This license does not allow the software to be rented or leased, and the written materials accompanying the software (if any) may not be copied. Limited Warranty. ArcSoft, Inc. And Ricoh, warrants that the software contained herein will perform substantially in accordance with the accompanying documentation. No Other Warranties. ArcSoft and Ricoh disclaims all other warranties, either express or implied, including but not limited to


The software contained on your CD is specially designed to operate with your RDC-7 digital camera. Please read the following information prior to installing your software to familiarize yourself with the contents of the CD.

### Software CD Contents and Installation - Macintosh



The ArcSoft folder contains the files necessary to install the ArcSoft Software Suite listed below onto your hard drive.

You will also find a folder that contains Adobe Acrobat and a PhotoIsland folder that contains a link to the PhotoIsland Web site.



**PhotoBase**, an easy-to-use program that organizes albums of multimedia files  
**PhotoStudio**, a full-featured, easy to use image editor.  
**PhotoMontage** lets you create a "mosaic" of a single image from a library of images.  
**PhotoPrinter** allows you to print multiple images on a single sheet.  
**PhotoFantasy** allows you to place personal images into background templates.  
**PhotoIsland** software lets you make free personal photo albums on the Web.  
**VideoImpressions** is an easy to use video editor  
**PanoramaMaker** lets you make 360 degree panoramics from your images



To install PhotoStudio and/or PhotoBase, you need to first select the language you wish to use.

Open the programs folder, select the language, and click on the installer icon.

The other Software Suite programs may be installed by just clicking on their installer from the ArcSoft folder.



This folder contains Ricoh Camera Utility DU-7, a simple serial file transfer utility for your RDC-7.

Double-click on installer icon to install the program to your hard disk.

A PDF file of the camera's upload/download instructions.

This program allows the RDC-7 to mount as a drive on your desktop for easy file transfer. Double-click on the mounter icon to install.

This TWAIN driver allows applications that support System 7.6 (or later) to acquire images directly from a Ricoh digital camera.



Double-click on the installer icon to install. Your system must be re-started prior to using the driver. Read the "Readme" file for more information.



This folder contains the drivers required to connect the camera to a USB port. Double-click on the RDC-7 USB driver icon to install. Your system must be re-started prior to using the driver. Read the "Readme" file for more information.

L211-2552

implied warranties of merchantability and fitness for a particular purpose, with respect to the Software, the accompanying written materials, and any accompanying hardware (if any). No Liability for Consequential Damages. In no event shall ArcSoft, Ricoh or its suppliers be liable for any damages whatsoever (including but not limited to damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss) which results from an inability to use this software, even if ArcSoft, Inc and Ricoh have been advised of the possibility of such damages. Because some states/jurisdictions do not allow the exclusion or limitation of consequential or incidental damages, the above limitations may not apply to you. U.S. Government Restricted Rights. The Software and documentation are provided with Restricted Rights. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1), (2), and (3) of the Commercial Computer Software - Restricted Rights at 48 CFR 52.227-19, as applicable, and any amendments thereto. The manufacturer is ArcSoft, Inc., 46601 Fremont Blvd., Fremont, CA 94538. If this product was purchased in the United States, this Agreement is governed by the laws of the state of California; Otherwise, local laws may apply.