

DOWNLOADING PROCEDURES WITH THE RDC-1

1. Attach the monitor and the RDT-1 Communications adapter to your Ricoh RDC-1 Digital Camera. If you did not purchase the Ricoh DM-1 Color Monitor, please connect the camera to another source such as a television using the AV outputs on the RDP-1 Playback adapter.
2. Connect the serial cable to the camera and to the serial port of your computer.
3. Ensure that the camera is turned off, however leave the camera monitor on.
4. Open the DU-1 software and under *Camera*, select *Display Camera Tool*.
5. Select the appropriate *Speed* and *Com Port*, then click *OK*.
6. Steps 7-10 need to be completed within 60 seconds of executing the DU-1 Software. If they are not, you will receive a message that the camera cannot connect. Please try again from step 4.
7. **Immediately** after executing, hold down the *Self Timer* button and put the camera on *Record*.
8. The monitor will ask you to select the cabling, use the zoom button to choose either *RS232C* (for PC) or *AUX* (for Mac).
9. Press *Start*.
10. Now select the appropriate *Baud Rate*, then press *Start*. The Baud Rate chosen here must match the rate chosen on the computer.
11. The monitor will then show the last image on the camera along with information regarding the image such as image number and size.
12. Your computer will now show the *Camera Tool*. The *Camera Tool* will now allow you to choose an image. If you click on the arrows, the camera monitor will display the appropriate image.
13. Click *Select* to choose an image to upload. Repeat this step for additional images. If you would like to upload all the images on the card, click *Select All*. If you choose the wrong image, click *Reset* or *Reset All*.
14. After selecting the image(s), click on *Copy the Selected Panel*. The computer will then ask you to choose a destination file. At this point the actual downloading begins.
15. If you would like to view the images downloaded, double click on the destination file. The images will then show up in thumbnail format. If you have more than 12 images, use the slide to view additional images.

If you receive an error message on your computer stating that the camera could not be connected, please check to ensure your serial cables are securely attached. If they are, check to ensure that the correct Com Port is being used.

Only the following types of images can be uploading with a serial cable:

- Stills
- Stills with Sound
- Sound
- Document